



# Samsung Galaxy S7 Screen Replacement

Learn how to replace the display and digitizer on your Samsung Galaxy S7.

Written By: Sam Lionheart

How To: Replace the Display on your Galaxy S7

A video thumbnail for a Samsung Galaxy S7 display replacement tutorial. It features a black Samsung Galaxy S7 smartphone centered against a solid blue background. The phone's camera and flash are visible at the top. Overlaid on the phone is the text 'Samsung Galaxy S7' in large white font, with 'Display Replacement' below it in a slightly smaller white font. At the bottom left, there is a white rectangular box containing the word 'iFIXIT' in black, and to its right, the word 'REPAIR' in a large, bold, blue font.

## Samsung Galaxy S7 Display Replacement

iFIXIT REPAIR

## INTRODUCTION

This guide will show you how to replace the screen on your S7. You will need to remove most components from the back of the display assembly, and then carefully pry the screen and digitizer off of the midframe. You will need to be very patient and careful to avoid damaging the soft button cables that wrap around the midframe.

This guide involves removing the rear glass cover, you will need replacement adhesive to reattach the back cover to the phone.

If your screen is badly shattered, wear eye protection, and apply a screen-protector, or tape, to the display to help contain glass shards.



### TOOLS:

- [Heat Gun](#) (1)  
*or iOpener*
- [Phillips #00 Screwdriver](#) (1)
- [iSlack](#) (1)  
*or suction cup*
- [Spudger](#) (1)
- [Plastic Cards](#) (1)
- [iFixit Opening Picks set of 6](#) (1)



### PARTS:

- [Galaxy S7 LCD Screen and Digitizer](#) (1)
- [Galaxy S7 Rear Cover Adhesive](#) (1)

To reassemble your device, apply the adhesive to the rear cover and follow these instructions in reverse order.

This document was last generated on 2017-06-18 07:36:01 AM.